



The new degree of comfort.™


TANKLESS GAS

TROUBLESHOOTING

POCKET MANUAL

SVC 820P

For Non-Condensing & Condensing Platforms



HEATING  COOLING  WATER HEATING

Rheem.com

This manual is specific to the following model numbers:

NON-CONDENSING

64DV, 64X / 70DV / 70X

84DV, 84X / 95DV, 95X

150DV, 150X / 160DV, 160X

180DV, 180X / 200DV, 200X

2-20RDV, 2-20ROF / 2-25RDV, 2-25ROF

2-28RDV, 2-28ROF

CONDENSING (up to -2 Models)

H-68DV, H-68X / H-84DV, H-84X

H-90DV, H-90X / H-95DV, H-95X

H-160DV, H-160X / H-180DV, H-180X

H-200DV, H-200X / H-25RDV, H-25ROF

H-32RDV, H-32ROF

Note: This guide does not cover RTGH-RH or RTGH-S models.

TABLE OF CONTENTS

General Information

Installation Guidelines.....	8
Condensing & Non-Condensing Flow Rates.....	13
Control Board Connectors.....	14
Diagnostic Points (Voltage & Resistance Readings).....	17
Maintenance Mode Instructions.....	22
Altitude Settings on Control Board.....	26
Reset Procedures.....	27
Clearing Fault History.....	28

Error Code Diagnostics

No Error Code & No Hot Water.....	29
P1 Warning Code.....	32
1L Warning Code.....	33
03 Error Code.....	35
05 Warning Code.....	36
10 Warning Code.....	38
11 Error Code.....	41
12 Error Code.....	47
13 Error Code.....	49
14 Error Code.....	51
15 Error Code.....	53
16 Error Code.....	54
24 Error Code.....	55
29 Error Code	
Condensing ONLY (A).....	56
Condensing & Non-Condensing (B).....	57
31 Error Code.....	59
32 Error Code.....	61
33 Error Code.....	63
34 Error Code.....	65
35 Error Code.....	67
51 Error Code.....	68
52 Error Code.....	71

61 Error Code.....	74
65 Error Code.....	77
66 Error Code.....	79
71 Error Code.....	80
72 Error Code.....	82
76 Error Code.....	85
Troubleshooting Remote Control	86
79 Error Code.....	88
80 Error Code.....	92
82 Error Code.....	95
90 Error Code.....	97
92 Warning Code.....	98
93 Error Code.....	98
99 Error Code.....	97

HOW TO REMOVE COMPONENTS

Section 1: Control Board Bracket...101

Section 2: Blower Motor...103

Section 3: Flame Rod; Igniter Rod; Igniter Coil...105

Section 4: Orifice Assembly...107

Section 5: Burner Assembly...109

Section 6: Gas Control Valve...110

Section 7: Water Control Valves...114

Section 8: Heat Exchanger Thermistor...117

Section 9: Outlet Thermistor...119

Section 10: Inlet Thermistor...121

Section 11: Ambient Thermistor...123

Section 12: Control Board...125

How to Program Control Board...126

Important Safety Information

READ the Safety Information

Before inspecting, diagnosing, repairing or operating any water heater, be sure to examine all of the safety and warning labels on the water heater. Follow the instruction on these warning labels. Read and understand the Use and Care Manual that was shipped with the water heater. Failure to do so can result in unsafe operation of the water heater resulting in property damage, bodily injury, or death. Should you have any problems reading or following the instructions in the Use and Care Manual, seek the help of a licensed and qualified professional.

ELECTRICAL SHOCK

Troubleshooting and repairing this water heater can expose you to electrical shock. Some of the diagnostic procedures require the presence of AC and DC volt electricity. Use extreme caution when performing these procedures. When replacing an unserviceable component, turn off all power to the water heater and check for the presence of power with a multi-meter or test lamp. The ignition cable carries more than 10,000 volts of electrical energy. Use extreme caution when diagnosing the Tankless Gas Water Heater.

FLAMMABLE LIQUIDS AND VAPORS Gasoline, as well as other flammable material and liquids (adhesives,

solvents, etc.), and vapors they produce are extremely dangerous.

DO NOT handle, use or store gasoline or other flammable or combustible materials anywhere near or in the vicinity of a water heater. The spark ignition and burner assembly in the water heater controls can ignite these vapors. Failure to do so can result in property damage, bodily injury or death.




WATER TEMPERATURE ADJUSTMENT

Safety and energy conservation are factors to be considered when selecting the water temperature setting on the thermostat. Water temperatures above 125° F can cause severe burns or death from scalding. The chart shown here may be used as a guide in determining the proper water temperature for your application.

TIME /TEMPERATURE RELATIONSHIPS IN SCALDS

Temperature	Time to Produce Serious Burn
120° F (49°C)	More than 5 minutes
125° F (52°C)	1 ¹ / ₂ to 2 minutes
130° F (54°C)	About 30 seconds
135° F (57°C)	About 10 seconds
140° F (60°C)	Less than 5 seconds
145° F (63°C)	Less than 3 seconds
150° F (66°C)	About 1 ¹ / ₂ seconds
155° F (68°C)	About 1 second
<small>Table courtesy of Shriners Burn Institute</small>	

Troubleshooting Tools

<p>Multi-Meter Used to measure Resistance & Voltage</p>	
<p>Multi-Meter Needle Set Used on meter test leads to access connectors while measuring Resistance & Voltage</p>	
<p>Manometer Used to measure gas pressure during standby and operation</p>	

SAFETY FIRST

*Your safety and safety of others is very important.
This manual is only intended for qualified service
technicians. ALWAYS USE CAUTION while testing
voltages and/or gas supply.*

MEASURING VOLTAGE & RESISTANCE


WARNING: WHILE MEASURING VOLTAGE, DO NOT cross/touch multi-meter leads together. This will cause damage to electrical components.

WHEN INSERTING LEADS INTO WIRING CONNECTOR, insert on the wiring side to prevent damage to connector.

BEFORE MEASURING RESISTANCE, TURN OFF all electrical power and make sure to REMOVE CONNECTOR from the circuit (control board). Check resistance on connector that was removed.

WHEN MEASURING VOLTAGE, DO NOT REMOVE CONNECTOR; insert multi-meter leads prior to operating unit.

WHEN MEASURING DC VOLTAGE, if the meter displays the dash (---) symbol, swap the position of your black and red leads on the connector.



***Installation Guidelines for
CONDENSING ONLY:***

GAS TYPE: Liquid Propane (LP) or Natural (NG)

NG MAX INLET GAS PRESSURE: 10.5 (In. of w.c.)

NG MIN INLET GAS PRESSURE: 4.0 (In. of w.c.)

LP MAX INLET GAS PRESSURE: 13.0 (In. of w.c.)

LP MIN INLET GAS PRESSURE: 8.0 (In. of w.c.)

MAX INPUT RATE: 199,900 (Btu/hr)

MIN INPUT RATE: 11,000 (Btu/hr)

GAS CONNECTION: 3/4" NPT

ELECTRICAL CONSUMPTION:

Normal: 100 W

Standby: 3-5 W

Antifreeze Protection: 200 W

MINIMUM ACTIVATION FLOW RATE (gpm): 0.4

EXTINCTION FLOW RATE (gpm): 0.25

VENT SIZE (Indoor ONLY): 2" or 3"

Installation Guidelines for CONDENSING ONLY:

The vent exhaust and air intake must be vented outside as described in the use and care manual. DO NOT vent this water heater through a chimney. It must be vented separately from all other appliances.

NOTICE: The unit can be vented using only the following recommended pipe material.

Use only 2 – or 3-inch diameter pipe. Refer to local codes for restrictions on the use of PVC, CPVC, or ABS pipe and fittings. All exhaust venting materials for product installed in Canada must meet ULC-S636.

Acceptable materials or equivalent:

PVC (Schedule 40, ASTM D-1785)

CPVC (Schedule 40, ASTM F-441)

ABS (Schedule 40, ASTM D-2661) (Not permitted in Canada)

The fittings other than the VENT TERMINAL should be equivalent to the following:

PVC (Schedule 40, DMW, ASTM D-2665)

CPVC (Schedule 40, DMW, ASTM F-438)

ABS (Schedule 40, DMW, ASTM D-2661)

(ABS Not permitted in Canada)

Category III Stainless Steel

DO NOT USE Schedule 20, Cell Core, Drain Pipe, Galvanized, Aluminum, B-Vent, or any flexible vent.

Approved Polypropylene Vent Manufacturer/Trade Name:

InnoFlue® by Centrotherm

Single Wall Pipe: ISVL**** or ISVL****UV

Elbow: ISELL**** or ISELL****UV

Adapter: ISAAL0202

Non-Return Valve (NRV): ISNRV****

Siphon: IASJBVS

Termination: ISLPT**** or ISTT****

(*Refers to variations in nominal size.)

Pre Dash, Dash 1

Number of 90 Degree Elbows	Maximum Length of 2" Straight Pipe	Maximum Length of 3" Straight Pipe
0 or 1	5'	38'
2	3' 6"	36' 6"
3	2'	35'
4	Not available	33' 6"
5	Not available	32'

Dash 2

Setting	Vent Size	Min Vent Length	Max Vent Length
A-1	3"	0%	15-20%
	2"	5%	15-20%
A-2	2"	10%	20-25%

Dash 2 A-1 Setting

Number of 90 Degree Elbows	Maximum Length of 2" Straight Pipe	Maximum Length of 3" Straight Pipe
1	22'	148' 6"
2	19'	147'
3	16'	145' 6"
4	13'	144'
5	10'	142' 6"
6	7'	141'

Dash 2 A-2 Setting (2" Pipe Only)

Number of 90 Degree Elbows	Minimum Length of 2" Straight Pipe	Maximum Length of 2" Straight Pipe	3" Pipe
1	22'	57'	Not Allowed
2	19'	54'	Not Allowed
3	16'	51'	Not Allowed
4	13'	48'	Not Allowed
5	10'	45'	Not Allowed
6	7'	42'	Not Allowed

***Refer to Use & Care Manual for the specific model for more details.**

Installation Guidelines for NON-CONDENSING ONLY:

GAS TYPE: Liquid Propane (LP) or Natural (NG)

NG MAX INLET GAS PRESSURE: 10.5 (In. of w.c.)

NG MIN INLET GAS PRESSURE: 4.0 (In. of w.c.)

LP MAX INLET GAS PRESSURE: 13.0 (In. of w.c.)

LP MIN INLET GAS PRESSURE: 8.0 (In. of w.c.)

MAX INPUT RATE: 199,900 (Btu/hr)

MIN INPUT RATE: 11,000 (Btu/hr)

GAS CONNECTION: 3/4" NPT

ELECTRICAL CONSUMPTION:

Normal: 100 W

Standby: 3-5 W

Antifreeze Protection: 200 W

MINIMUM ACTIVATION FLOW RATE (gpm): 0.4

EXTINCTION FLOW RATE (gpm): 0.25

VENT SIZE (Indoor ONLY): 3"/5" concentric

Installation Guidelines for NON-CONDENSING ONLY:

WARNING:

- Use 3-in. /5-in. UL-approved Category III Stainless Steel vent materials or water heater manufacturer-approved vent material. No other vent material is permitted for use with this appliance.

Venting Requirements

The installation of the venting must comply with national codes, local codes and the vent manufacturer's instructions.

The water heater must be vented to the outdoors. DO NOT vent this water heater through a chimney. It must be vented separately from all other appliances.

All coaxial vent components (adapters, pipe, elbows, terminals, etc.) should be water heater manufacturer-approved Stainless Steel Venting Material (e.g., AL29-4C).

Number of 90 Degree Elbows (bends)	Maximum Length of Straight Pipe
1	39'
2	37' 6"
3	36'
4	34' 6"
5	33'
6	31' 6"

NON-CONDENSING UNIT FLOW RATES**64DV & 64X**

Temperature Rise (° F)								
35	45	50	60	70	77	80	90	100
6.4	5.6	5.1	4.2	3.6	3.3	3.2	2.8	2.5
Max Water Flow - GPM (gallons per minute)								

70DV & 70X

Temperature Rise (° F)								
35	45	50	60	67	70	80	90	100
7.0	6.0	5.4	4.5	4.1	3.9	3.4	3.0	2.7
Max Water Flow - GPM (gallons per minute)								

84DV & 84X

Temperature Rise (° F)								
35	45	50	60	67	70	80	90	100
8.4	6.7	6.1	5.1	4.5	4.3	3.8	3.4	3.0
Max Water Flow - GPM (gallons per minute)								

95DV & 95X

Temperature Rise (° F)								
35	45	50	60	67	70	80	90	100
9.5	7.4	6.6	5.5	5.0	4.7	4.1	3.7	3.3
Max Water Flow - GPM (gallons per minute)								

CONDENSING UNIT FLOW RATES**H68DV & H68X**

Temperature Rise (° F)								
35	45	50	60	67	70	80	90	100
6.6	5.1	4.6	3.8	3.4	3.3	2.9	2.6	2.3
Max Water Flow - GPM (gallons per minute)								

H84DV & H84X


Temperature Rise (° F)								
35	45	50	60	67	70	80	90	100
8.4	6.7	6.0	5.0	4.6	4.3	3.8	3.3	3.0
Max Water Flow - GPM (gallons per minute)								

H90DV & H90X

Temperature Rise (° F)								
35	45	50	60	67	70	80	90	100
9.0	7.7	6.9	5.8	5.2	4.9	4.3	3.8	3.5
Max Water Flow - GPM (gallons per minute)								

H95DV & H95X


Temperature Rise (° F)								
35	45	50	60	67	70	80	90	100
9.5	8.5	7.7	6.4	5.7	5.5	4.8	4.3	3.8
Max Water Flow - GPM (gallons per minute)								



*****FUEL TYPE CHIP*** – When replacing Control Board, you must use the original chip on the new Control Board. New Control Board must be programmed (refer to page 125).**

- | | |
|--|---|
| <ul style="list-style-type: none"> P – Red, Red (Condensing ONLY) M – White Molex: Grey T – Blue Molex: Blue (Indoor Models ONLY) K – Red, Black, Green, Yellow, White, Grey, Blue H – White, White, Grey, Grey U – White, White S – Brown, Black, Red C – Brown, White, Orange, Blue, Yellow, Green, Red, Black B - Brown, White, Orange, Blue, Yellow, Green, Red, Black G – Indoor Units: Blue, Yellow, White, Black, Red G – Outdoor Units: Yellow, Orange, Red, Blue, White R – Non-Condensing: Red, Black, Black, Red, Yellow, White, Blue R – Condensing: Red, Black, Black, Red, Green, White, Blue | <p>Connector Wire
Colors</p> |
|--|---|

CONTROL BOARD CONNECTORS



Diagnostic Points on Control Board

Connection	Wire Color	Normal Value	What are you checking?
I – J	W1-BK2	AC108-132V	Do you have power to the control board?
U	W1-W2	50K Ω -500K Ω	Is the overheat film wrap OK?
S	BR1-BK2	DC 2-5V (Pulse) More than 1,310 pulses/minute	Does the water flow sensor send a pulse? (Only when water is flowing thru the unit)
S	R3-BK2	DC 11-17V	Does the water flow sensor have voltage? (Power ON; no water flow)

Connection	Wire Color	Normal Value	What are you checking?
G	BK4-R6	DC 144-192V	Does the fan motor have the proper voltage?
	W3-BK4	DC 12-18V	Is the overheat film wrap OK?
	BR1-BK2	DC 4-10V (Pulse)	Is the fan motor producing regular pulse?
R	W6-BK3	68°F=10.3KΩ 104°F=4.9KΩ	Is the water inlet thermistor working?
R	<i>Non-Condensing:</i> Y5-BK3 <hr/> <i>Condensing:</i> G5-BK3	68°F=10.3KΩ 104°F=4.9KΩ	Is the heat exchanger thermistor working?

Connection	Wire Color	Normal Value	What are you checking?
R	R4-BK3	68°F=10.3KΩ 104°F=4.9KΩ	Is the water outlet thermistor working?
R	BL7-BK4	<i>Non-Condensing INDOOR Units:</i> 68°F=10.3KΩ 104°F=4.9KΩ <hr/> <i>ALL OUTDOOR & ALL CONDENSING units:</i> 68°F=10.3KΩ 104°F=4.9KΩ	Is the ambient air thermistor working?

Connection	Wire Color	Normal Value	What are you checking?
R	R1-BK2	DC1.5-14V 40Ω-80Ω	Is the P.G.F.R. valve operating? (Proportional Gas Flow Regulator – full modulating valve)
M	W1-GND	AC 1-100 V	Flame rod detecting flame?
T	BL1-GND	AC 1-100 V	Flame rod detecting flame?
H	GY3-GY4	AC 108-132 V	Is the igniter working properly?

Connection	Wire Color	Normal Value	What are you checking?
K	Y1-BK6	DC 90-120 V 0.8K Ω -2.4K Ω	Gas inlet solenoid valve OK?
K	W2-BK6	DC 90-120 V 0.8K Ω -2.4K Ω	Solenoid valve 1 OK?
K	GY3-BK6	DC 90-120 V 0.8K Ω -2.4K Ω	Solenoid valve 2 OK?
K	R5-BK6	DC 90-120 V 0.8K Ω -2.4K Ω	Solenoid valve 3 OK?
K	BL4-BK6	DC 90-120 V 0.8K Ω -2.4K Ω	Solenoid valve 4 OK?

Maintenance Mode Panel Display

INSTRUCTIONS

The Rheem/Ruud Tankless has a maintenance mode chart on the remote control. To access the maintenance mode, turn the unit OFF at remote control and make sure water flow is OFF. Then hold down the UP and DOWN arrow keys at the same time for 5 seconds. You will hear an audible beep and see the display go to 1E (NOTE: Unit will default to 120° F). By pressing the UP and DOWN arrow keys on the remote control, you can access a variety of information about the water heater. To activate the unit while displaying the maintenance panel: push the power button once, open a hot water fixture, and the green LED will illuminate. This will allow you to access a variety of real time information while the unit is in operation.

Shortcut: (See Diagram on Page 23) DIP1 - Lift dip switch #1 to the up position to go immediately into maintenance mode. This can be done while the water heater is in operation.

(NOTE: Unit will maintain the set temperature)

While in maintenance mode you want to push the UP arrow key to select the table you wish to view. The table is designated by a letter and is always displayed as the second digit. Then push the DOWN arrow key to display the number item in the table you selected. The number is always displayed as the first digit. You can select as many as 8 readings for each table.


To perform diagnostics in this service manual, press the UP arrow until you get to table **1Y**.

Now using your DOWN arrow you can change the number in front of **Y**. As you move through the diagnostic readings, the selected table will flash first and then the diagnostic reading.


(Maintenance Mode Table on Page 24)

You will see the following as you navigate the Y table in maintenance mode:

- 0Y** = Flame rod status
- 1Y** = Water flow in gallons per minute
- 2Y** = Ambient air temperature
- 3Y** = Water inlet temperature
- 4Y** = Heat exchanger temperature
- 5Y** = Hot water outlet temperature
- 6Y** = Fan speed (x 100 rpm)
- 7Y** = Power for modulating gas valve
- 8Y** = Null (no reading)
- 9Y** = Null (no reading)



Altitude Settings on Control Board



Locate the two DIP switches at top right of Control Board. Switch labeled DIP2 is the bottom switch. Altitude adjustments must be performed on DIP2 ONLY.


<p>DIP2</p> <p>ON</p> <p>1 2 3 4</p> <p>OFF</p>	<p>Sea Level (0ft – 2000ft)</p> <p>All switches should be in the OFF position (DOWN)</p>
<p>DIP2</p> <p>ON</p> <p>1 2 3 4</p> <p>OFF</p>	<p>2000ft – 5400ft</p> <p>3RD switch should be in the ON position (UP)</p>
<p>DIP2</p> <p>ON</p> <p>1 2 3 4</p> <p>OFF</p>	<p>5400ft – 8500ft*</p> <p>4TH switch should be in the ON position (UP)</p>

*Older models could go up to 9840ft.

RESET PROCEDURE


ONLY for 'Hard Lockouts' - Error Codes: 10, 13 & 99

1. Turn remote control OFF; leave unit plugged in. Remove front cover. Locate the DIP Switches (Upper Right on the control board).
2. Make sure all the DIP Switches are OFF (down position).
3. Locate DIP1 – Switch #2 and turn it ON (up position) then immediately turn it OFF.
4. Within 5 seconds, press and hold the MIN and MAX buttons for at least 2 seconds.
5. The remote control will flash "UL" then it will go solid. This indicates the heater has been reset.
6. Release the buttons.
7. Turn remote control ON. You may operate unit.



CLEARING FAULT HISTORY

1. Turn remote control OFF; leave unit plugged in. Remove front cover. Locate the DIP Switches (Upper Right on the control board).
2. Make sure all the DIP Switches are OFF (down position).
3. Locate DIP1 – Switch #1 and turn it ON (up position) then immediately turn it OFF.
4. Within 5 seconds, press and hold the MIN or MAX button for at least 2 seconds.
5. The remote control will flash “CL” then it will go solid. This indicates the fault history has been cleared.
6. Release the buttons.
7. You can verify clearing history by entering maintenance mode and check the code at location 1E. Should read NULL (-- two dashes).
8. Turn remote control ON. You may operate unit.



No Error Code & No Hot Water

Explanation: No hot water is delivered when water is flowing through unit and remote control displays the hot water temperature setting. [For 'NO POWER' complaint (remote control will not turn on) – check wall outlet for 120 volts. If voltage is present, check the two 3-amp fuses at the control board]

Possible Causes:

- Water flow (0.4 GPM to activate)
- DIP1 setting on main control board
- Water flow sensor
- Check for clogged impeller
- Blown fuses

Water Flow:


1. Use cold water shutoff valve to turn OFF water supply to unit. Turn remote control OFF; unplug power cord at wall outlet. Wait 10 seconds; plug power cord back into outlet; wait 20 seconds; turn the remote control ON. Turn water supply ON; check the nearest hot water fixture for hot water.
2. Open multiple hot water fixtures. If unit fires then there is not enough water flow to engage the unit at a particular fixture. Check your fixture aerator screen(s) for debris. Clean if necessary.
3. Your water flow may be restricted by debris in water filter. Remove the water filter and inspect. Clean if necessary.
4. Your water lines might be crossed. Make sure your hot and cold water supply lines are connected to the appropriate hot and cold water assembly connections on the unit.

Water Flow Continued:

5. Check impeller for clog. Pull and clean.
6. Replace fuses, if they blow again, replace board and blower.

Single Unit Installations ONLY:

All DIP1 switches must be in the 'OFF' position (DOWN).

**Manifold (Multiple) Unit Installations ONLY:**

Go to 03 - Error Code to verify proper DIP1 setting.

Water Flow Sensor:

FINAL CHECK: Water flow sensor in water volume control valve.

Check connector 'S' between the Red and Black wires.

With the unit ON and no water flow, you should read 11-17 DC volts. If not, replace the control board. If you have voltage, then.....

With the water flowing, measure 2-5 DC volts between the Brown and Black wire. (This is measuring water flow thru the control). If you have a reading and no main burner, replace the control board. If you do not have a reading, remove any debris from water volume control valve.

Connector Location
On Page 14

P1 - Warning Code

Explanation: No hot water is delivered when water is flowing through unit and remote control displays P1 - Warning Code.


Possible Causes:

- *Not Enough Water Flow*
1. Turn the water supply to the unit OFF. Turn the remote control OFF, wait 10 seconds and turn the remote control ON. Turn the water supply to the unit ON and check the nearest hot water fixture for hot water. If you have hot water, then the unit needed to be reset.
 2. Your water lines might be crossed. Make sure your hot and cold water supply lines are connected to the appropriate hot and cold water connections on the unit.
 3. Your water flow may be restricted by a dirty In-Line Water Filter. Remove the water filter and inspect. Clean if necessary.
 4. Possible plumbing cross-over in the home. Turn OFF hot water valve to the water heater. Go to each water fixture in the home and turn ON the hot water ONLY (test washing machine by setting it to hot ONLY). If water flows freely through the hot water side of the fixture, this is a plumbing crossover. **HINT:** During this test, to prevent scalding, pressure-balancing valves on single-handle fixtures will not allow any water to flow if there is a plumbing crossover.
 5. Water flow might be too low. Open multiple hot water fixtures. If unit fires then there is not enough water flow to engage the unit at a particular fixture. Check your fixture aerator screen(s) for debris. Clean if necessary. **FOR RECIRCULATION LINES:** check pump size, aqua-stat, check valve, and operation.

1L - Warning Code

Explanation: The control board has detected lime build-up inside the heat exchanger. To prevent permanent damage to the unit, the unit must be drained and flushed. Flushing procedures may need to be repeated for excessive lime and scale build-up.

***To reset 1L Code, hold down the MIN and MAX buttons at the same time for 10 seconds**



NOTE: Flushing instructions utilize a submersible utility pump (provided with the Rheem/Ruud Tankless Flush Kit – RTG20124)

1. Turn OFF gas and both the cold and hot water supply to the water heater. The gas must remain OFF during the flushing process.
2. At the remote control, turn OFF the power and wait 10 seconds. Turn ON the power and wait 10 seconds. Disconnect the water heater from the electrical source.
3. Connect a hose to the hose connections on the service valves under the water heater.
4. Place the loose end of the hoses into a 5-gallon bucket.
5. Open the service port valve on each side of the service valves, to allow the heater to drain. Connect the cold water side hose to the outlet side of the utility pump and set the pump into the bottom of the bucket.
6. Pour 2 gallons of **virgin food grade white vinegar** into the bucket and turn the pump ON.
7. Allow the pump to circulate the vinegar for 45 to 60 minutes. (time will vary depending upon mineral build-up and hardness of the water)
8. Turn OFF the pump and remove the hose from the pump. Allow the vinegar to drain from water heater into the bucket.
9. Place the hot water side hose in another bucket or route it to a suitable drain.
10. Close the service port valve on the cold water side and disconnect the cold water hose from the service valve.
11. Follow instructions in the Use & Care manual, supplied with the water heater, to clean the water inlet filter.
12. Turn ON the cold water supply to the heater. **DO NOT TURN ON THE HOT WATER SUPPLY TO THE HEATER.** Water will begin to flow through the heater; this will rinse out any remaining vinegar from the water heater. Allow the water to run for approximately 5 minutes.
13. Close the hot water service port valve and disconnect the drain hose.
14. Open a hot water fixture in the home, such as a tub. Allow the water to flow for a minute to ensure there is no air remaining in the system. Turn OFF the hot water fixture.
15. Reconnect power to water heater, turn ON gas supply, and turn ON power at the remote control.
16. Turn ON a hot water fixture to ensure the water heater is operating.

03 - Error Code

**Only for manifold (multiple) unit installations:
EZ-Link; MIC-6; or MIC-185 manifold controllers.**

Explanation: Communication failure between water heaters, remote control, and/or manifold controller.

Diagnostic Checks:


- *DIP1 setting on main control board (PCB)*

DIP1 SETTING:

Manifold units only: DIP1, switch #4 must be in the 'ON' position (UP) for each unit.

Check ALL Molex connections on ALL control boards.

Control Board Layout for third generation models



**If 03 - Error Code is displayed after completing all checks: Call
Technical Support (800)-432-8373**


05 – Warning Code

Explanation: The flame rod has detected improper burner combustion (Indoor Units ONLY). This warning code is commonly caused by VENTING and/or GAS SUPPLY.

Diagnostic Checks:

- **GAS SUPPLY & VENTING** (refer to pages 8-12)
- **DIP2 setting on main control board**

Make sure DIP2 on control board is set to the correct altitude. Refer to Page 25 for altitude settings.



10 – Warning Code

Explanation: Unit was operated prior to vent installation OR blower motor is not creating enough ventilation.

First: Follow reset procedure on page 26.

Next: Check VENTING.

Diagnostic Checks:

- **VENTING (refer to pages 8-12)**
- Blower motor

Remove control board bracket. (How to remove: Section 1)
Remove blower motor. (How to remove: Section 2)
Clean blower motor and blower motor housing.
Reassemble & operate unit.

Does 10-Warning Code appear?

YES

Locate MIN & MAX buttons on upper right-hand corner of control board.

Continue diagnostics on next page.


NO

Blower motor needed to be cleaned or you had a loose connection.


Unit appears to be operating OK.

MIN & MAX
BUTTONS

CONTROL
BRACKET




Blower Motor Diagnostics: INDOOR Models ONLY




IMPORTANT: While performing voltage checks, **DO NOT** touch multimeter leads across **BLUE & White** wires. Damage may occur to blower motor and control board.

Upper Right-Hand Corner of Control Board




Blower Motor Diagnostics: OUTDOOR Models ONLY



IMPORTANT: While performing voltage checks, **DO NOT** touch multimeter leads across **YELLOW & RED** wires. Damage may occur to blower motor and control board.

Upper Right-Hand Corner of Control Board



11 – Error Code

Explanation: Flame rod(s) does not detect flame.
Commonly GAS SUPPLY and/or VENTING.



IMPORTANT: If all water heater components test 'OK', you must thoroughly inspect your GAS SUPPLY & VENTING.



HINT: Make sure DIP2 (altitude setting) is properly set – see Page 26

Diagnostic Checks:

- **GAS SUPPLY & VENTING (refer to pages 8-12)**
- Igniter rod
- Flame rod(s)
- Gas control valve

**Connector Location
On Page 14**

Igniter Rod Diagnostics (spark is NOT visible)

Turn Power OFF.
Remove and reinsert: connector 'H' (White Molex on bottom of igniter coil) & black insulated igniter cable on igniter rod.

Turn Power ON.
Operate unit and determine IF spark is visible through sight glass.

YES


You had a loose connection.

Igniter is OK.

NO


Continue diagnostic on next page.

SIGHT GLASS





IGNITER ROD

IGNITER COIL

Igniter Rod Diagnostics (spark is NOT visible)

HINT: During the igniter start there will be a distinct click when the spark arcs.



Flame Rod Diagnostics (flame IS visible)

Turn Power OFF.
Remove and reinsert connector "M", "T", and terminal on flame rod(s).
Turn Power ON.
While viewing through sight glass, operate unit to determine IF flame is touching the flame rod(s).
Indoor models – 2 flame rods (Connectors "M" & "T").
Outdoor models – 1 flame rod (Connector "M").



Access maintenance mode to check flame rod status & continue to diagnostic chart on next page.




Remove any foreign debris. IF foreign debris is not present: CHECK GAS SUPPLY & VENTING.


(See maintenance mode instructions on page 22)

FLAME ROD(S)

SIGHT GLASS



Flame Rod(s) Diagnostics



Outdoor: 1 flame rod
White Molex – Grey Wire



Indoor: 2 flame rods
White Molex – Grey Wire
Blue Molex – Blue Wire



Gas Control Valve Diagnostics (Igniter Rod Sparks & NO flame)



IMPORTANT: DURING VOLTAGE CHECKS – CONNECTOR “K” ONLY
(water is flowing and unit is attempting to ignite):
IF you do NOT get a voltage reading, push and hold the MAX button on upper right hand corner of control board to activate unit at full BTU's.
This will force voltage to ALL gas valve solenoids during diagnostics.

CAUTION: DO NOT hold MAX button down for more than 5 Seconds
MAY CAUSE DAMAGE TO THE HEAT EXCHANGER.

Turn Power OFF.
Remove and reinsert connectors “K” & “R”.
(Connector “K” is Gas Valves.
Connector “R” is PGFR valve.)
Locate PGFR valve on lower right side of unit
(round black piece on bottom of gas valve.
PGFR is a full modulating gas valve).
Remove and reinsert Molex connectors with
Red and Black wires on PGFR.

Turn Power ON


While viewing through sight glass, operate unit to
determine IF flame is visible.




You had a loose connection.
Gas control valve is OK.



Continue diagnostics on
next page.



MAX




Connector Location
On Page 14

GAS VALVE

PGFR

Gas Control Valve Diagnostics



12 – Error Code

Explanation: Commonly GAS SUPPLY and/or VENTING.
Unit detected the presence of flame and then lost it.



HINT:: Make sure DIP2 (altitude setting) is properly set – see Page 26

Diagnostic Checks:

- GAS SUPPLY & VENTING (refer to pages 8-12)
- Flame rod(s)

Turn Power OFF.
Remove and reinsert connector ‘M’; ‘T’;
and terminal on flame rod(s).

Turn Power ON.
While viewing through sight glass, operate unit to determine
IF flame is touching the flame rod(s).

Indoor models – 2 flame rods (Connectors ‘M’ & ‘T’).

Outdoor models – 1 flame rod (Connector ‘M’).



Access maintenance mode to check flame rod status & continue to diagnostic chart on next page.




Remove any foreign debris. IF foreign debris is not present: CHECK GAS SUPPLY & VENTING.


(See maintenance mode instructions on page 22)

FLAME ROD(S)

SIGHT GLASS

**Connector Location
On Page 14**





HINT: You can use scotch-brite, fine Steel Wool or paper money to clean Ignitor and flame rods. Emory cloth, sand paper, scraping with pocket knife, etc. is too damaging to the rod.



Outdoor: 1 flame rod
White Molex – Grey Wire



Indoor: 2 flame rods
White Molex – Grey Wire
Blue Molex – Blue Wire



13 – Error Code


Explanation: Indoor units ONLY. Flame rod is detecting poor combustion. This is commonly caused by inadequate GAS SUPPLY and/or VENTING.




HINT: Make sure DIP2 (altitude setting) is properly set – see Page 26
(If unit shuts down 5 times within a 4 hour period due to 13 – Error Code, the unit must be reset by performing reset procedure on page 27).


Diagnostic Checks:

- **GAS SUPPLY & VENTING (refer to pages 8-12)**
- Flame rod FL-2



(See maintenance mode instructions on page 22)





HINT: You can use scotch-brite, fine Steel Wool or paper money to clean Ignitor and flame rods. Emory cloth, sand paper, scraping with pocket knife, etc. is too damaging to the rod.



Indoor: 2 flame rods
 White Molex – Grey Wire
 Blue Molex – Blue Wire



14 – Error Code

Explanation: OHL (Over Heat Limiter) or Over Temp Limit Switch activated. IF the OHL or Over Temp Limit Switch has been activated, this is normally caused by inadequate/wrong GAS SUPPLY and/or VENTING.

CHECK GAS SUPPLY & VENTING (refer to pages 8-12).

Diagnostic Checks:

- OHL – Check for damage.
- Condensing ONLY: Over Temp Limit Switch (monitors vent temperature)

Connector Location
On Page 14

Turn Power OFF.
Remove & reinsert connector "U".
Attempt to operate unit.

Does 14 – Error Code appear?


YES


Continue to diagnostic chart on next page.

NO


Unit had a loose connection or over temp limit switch cooled down. Unit appears to be operating OK.

**Condensing Indoor (condensing) ONLY:
Locate the Over Temp Limit Switch (circled in red)**





**Over Temp Limit Switch - Condensing Indoor
(Condensing) ONLY:**



15 – Error Code

Explanation: The hot water temperature and/or heat exchanger temperature reached 207 degrees F for more than 15 seconds.



IMPORTANT: Inadequate GAS SUPPLY and/or VENTING will create hot spots in the heat exchanger.

Diagnostic Checks:

- **GAS SUPPLY & VENTING (refer to pages 8-12)**
- Sediment build-up in heat exchanger
- Heat exchanger thermistor

Sediment Build-Up Diagnostics

Go to Error Code 1L for flushing instructions. (Refer Pg.33)

Heat Exchanger Thermistor Diagnostics

Go to Error Code - 32 for heat exchanger thermistor diagnostic instructions. (Refer Pg.61)

16 – Error Code

Explanation: Outlet water temperature is above the set point on the remote control.



IMPORTANT: Check the outlet thermistor FIRST.

Diagnostic Checks:

- Outlet thermistor
- Water bypass valve

Outlet Thermistor Diagnostics:

Go to Error Code 33 for outlet thermistor diagnostic instructions. (Refer Pg.63)

Water Bypass Valve Diagnostics:

Go to Error Code 66 for water bypass valve diagnostic instructions. (Refer Pg.79)

Y-Check:


Check the Y-Checks on starting on Page 22 (Maintenance Mode) for checking all thermistors. If readings are irrational, verify readings with voltmeter reading.

24 – Error Code

Explanation: Remote control buttons were depressed for more than 20 seconds, release buttons and operate unit. IF error code 24 appears again, continue to remote control diagnostics.

Diagnostic Checks:

- Remote control



29 – Error Code (A)



Explanation: Condensing Units ONLY: Condensation is NOT draining.

Diagnostic Checks:

- Plug not removed from condensate drain
- Pinch in condensate drain line
- Blockage in condensate drain line
- Drain line has unnecessary “P” trap

Condensate Drain Diagnostics:

1. Ensure you removed the condensate protection plug located at bottom of unit & attached a condensate drain line to the unit.
2. Check condensate drain line for internal or external blockage. Make sure drain line is NOT pinched.
3. Remove “P” trap on condensate drain line.



29 – Error Code (B)

Explanation: Heat exchanger temperature too low for more than 3 minutes.



HINT: Condensing Units ONLY:
make sure condensate is draining properly
prior to continuing diagnostics
(go to previous page for diagnostics).

Diagnostic Checks:

- Inlet & heat exchanger thermistors
- Gas control valve
- Water volume control valve

Inlet thermistor Diagnostics:

Go to 31 – Error Code. (Refer Pg.59)

Connector Location
On Page 14

Heat Exchanger thermistor Diagnostics:

Go to 32 – Error Code. (Refer Pg. 61)



HINT: ALWAYS diagnose thermistors before
continuing to next steps.

Turn power OFF.
Remove connector "R" and
measure resistance across #1 wire (Red)
and #2 wire (Black):
40-80 OHMS

Remove connector "K". Using the BLACK WIRE
as the common – Individually check resistance for
Yellow, White, Red, & Blue wires:
0.8K – 2.4K OHMS

YES

Continue to diagnostic chart on
next page.

NO

Replace gas control valve.


Calculate Temperature Rise & Gallons per Minute:

1. Enter maintenance mode & select table 3Y. Turn on water flow to determine inlet water temperature.
2. Using the formula below, determine temperature rise.

Remote control temp - Incoming water temp = Temperature Rise

3. Select table 1Y. Using the incoming water shut off valve Turn OFF incoming water at the unit. Turn ON ALL hot water fixtures in the home/business to full flow. Using the incoming water shut-off valve, turn ON incoming water at unit. Determine MAX GPM flowing through unit.

***BEFORE continuing - Refer to pages 13 & 14 to obtain MAX GPM possible for appropriate model number.**



Maintenance Mode
Instructions on Page 22

31 – Error Code

Explanation: Inlet thermistor malfunction.

Diagnostic Checks:

- Inlet thermistor

Turn Power OFF.
Remove connector "R". Measure resistance
between #3 wire (Black) & #6 wire (White):

7K – 23K Ohms

YES


Reinsert connector "R".
Operate unit.
IF Error Code 31 appears:
Replace control board.


NO

Remove control board bracket
to access inlet thermistor Molex
near
blower motor
(How to Remove: Section 1).
Continue diagnostics
on next page.


Connector Location
On Page 14

CONTROL
BRACKET





Molex Connectors



32 – Error Code

Explanation: Heat exchanger thermistor malfunction.

Diagnostic Checks:

- Heat exchanger thermistor

Turn Power OFF. Remove connector "R":

Non-Condensing Units ONLY: Measure resistance between #3 wire (Black) & #5 wire (YELLOW):

Condensing Units ONLY: Measure resistance between #3 wire (Black) & #5 wire (GREEN):

7K – 23K OHMS

YES


Reinsert connector "R".
Operate unit.
IF Error Code 32 appears:
Replace control board.


NO

Remove control board bracket
to access heat exchanger
thermistor Molex near
blower motor
(How to Remove: Section 1).
Continue diagnostics
on next page.


Connector Location
On Page 14

CONTROL
BRACKET





Molex Connectors



33 – Error Code

Explanation: Outlet thermistor malfunction.

Diagnostic Checks:

- Outlet thermistor

Turn Power OFF.
Remove connector "R":
Measure resistance between
#3 wire (Black) & #4 wire (RED):
7K – 23K OHMS

YES


Reinsert connector "R".
Operate unit.
IF Error Code 33 appears:
Replace control board.


NO

Remove control board bracket
to access outlet thermistor
Molex near
blower motor
(How to Remove: Section 1).
Continue diagnostics
on next page.


Connector Location
On Page 14

CONTROL
BRACKET





Molex Connectors



34 – Error Code

Explanation: Ambient thermistor malfunction.

Diagnostic Checks:

- Ambient thermistor

Turn Power OFF. Remove connector "R":

Measure resistance between
#3 wire (Black) & #7 wire (Blue):

64DV; 84DV; 95DV: 7K – 23K Ohms

64X; 84X; 95X; H95X; H95DV: 2K – 72K Ohms

YES


Reinsert connector "R".
Operate unit.
IF Error Code 34 appears:
Replace control board.

NO

Remove control board bracket
to access ambient thermistor
Molex near
blower motor
(How to Remove: Section 1).
Continue diagnostics
on next page.

Connector Location
On Page 14

CONTROL
BRACKET



Locate & separate Blue Molex (located near blower motor). Check resistance across White wires on female end of Molex:

2K – 72K Ohms

7K – 23K Ohms

NO

Clean scale build-up ambient thermistor. Reassemble and operate unit. IF Error Code 34 appears:

Replace ambient thermistor.

YES

Reconnect Molex. Check resistance on connector "R" between #3 wire (Black) and #7 wire (Blue):

2K – 72K Ohms

7K – 23K Ohms


NO

Replace wiring harness for connector "R" on control board.

YES

Reinsert connector "R". Operate unit. IF 34 - Error Code appears: Replace control board.

Molex Connectors



35 – Error Code

Explanation: Improper thermistor connection. Unit has four thermistors; one or more possibly has a poor connection or not connected in proper location.

Diagnostic Checks:

- Inlet, heat exchanger, outlet, & ambient thermistors

Connector Location
On Page 14

Turn Power OFF. Remove connector "R".

Turn Power ON. Operate Unit".

Does 35 – Error Code Appear?


YES

Test ALL thermistors.
Follow Instructions for:

31 – Error Code
32 – Error Code
33 – Error Code
34 – Error Code

NO

Unit had a loose connection.
Thermistors appear to be OK.



51 – Error Code

Explanation: Gas control valve malfunction. Unit detected the presence of flame when demand for hot water terminated & the unit turned OFF.

Diagnostic Checks:

- Flame rod(s)
- Gas control valve

Connector Location
On Page 14

Turn Power OFF.
Remove and reinsert connector "M", "T",
and terminal on flame rod(s).
Turn Power ON. Operate unit.

Did 51 – Error Code appear?

Indoor models – 2 flame rods (Connectors "M" & "T").
Outdoor models – 1 flame rod (Connector "M").



Access maintenance mode to check flame rod status.
Locate sight glass.
Continue to diagnostic chart on next page





Unit had a loose connection or foreign debris that is no longer present.
Thermistors appear to be OK.

(See maintenance mode instructions on page 22)

FLAME ROD(S)

SIGHT GLASS





Outdoor: 1 flame rod




Indoor: 2 flame rods



On remote control, go to maintenance mode 0Y table. For maintenance mode instructions go to page 21.

All maintenance mode '0Y' readings should be done immediately after turning the unit OFF. IF Flame Rod(s) is detecting flame, maintenance mode will display:

Indoor Units: **05**
 Outdoor Units: **01**



On remote control, go to maintenance mode OY table.
For maintenance mode instructions go to page 21.

All maintenance mode 'OY' readings should be done immediately after turning the unit OFF.

IF Flame Rod(s) is detecting flame, maintenance mode will display:
Indoor Units: **05**
Outdoor Units: **01**

52 – Error Code

Explanation: PGFR malfunction. The PGFR is the only modulating valve in the gas control valve.

Diagnostics: PGFR (Proportional Gas Flow Regulator)

Turn Power OFF.
Remove and reinsert connector "R".

Locate PGFR valve on lower right side of unit (round black piece on bottom of gas control valve).
Remove and reinsert Molex connectors with Red and Black wires on PGFR.

Operate unit.
While viewing through sight glass,
determine if flame is visible.




Unit had a loose connection
Gas control valve is OK.



IF 52 – Error Code appears and
flame IS visible:
Replace gas control valve



Continue diagnostics on
next page.

Connector Location
On Page 14







61 – Error Code


Explanation: The Blower motor speed was not appropriate to allow proper combustion.

Diagnostic Checks:

- Blower motor




Blower Motor Diagnostics: Indoor Models ONLY




IMPORTANT: While performing voltage checks, **DO NOT** touch multimeter leads across **BLUE & White** wires. Damage may occur to blower motor and control board.

Upper Right-Hand Corner of Control Board




Blower Motor Diagnostics: Outdoor Models ONLY



IMPORTANT: While performing voltage checks, **DO NOT** touch multimeter leads across **YELLOW & RED** wires. Damage may occur to blower motor and control board.

Upper Right-Hand Corner of Control Board



65 – Error Code

Explanation: Water volume control valve malfunction.

Diagnostic Checks:

- Water volume control valve

Connector Location
On Page 14



IMPORTANT: The water volume control valve will only activate IF demand for hot water EXCEEDS the unit's limitations. If water flow is within the unit's limitations, you will not get a voltage reading for diagnostics.



Turn on all hot water fixtures to activate water control valve (refer to 29 – Error Code (B) Page 57).

Turn Power Off, Remove & Reinsert connector "C".
Remove control board bracket. (*How to remove: Section 1*)
Visually inspect water volume control valve for loose or damaged connections
Reassemble & operate unit.

Does 10-Warning Code appear?

YES


Locate MIN & MAX buttons on upper right-hand corner of control board.

Continue diagnostics on next page.


NO

Blower motor needed to be cleaned or you had a loose connection.

Unit appears to be operating OK.



Water volume control valve, located to right of blower motor, connected directly to water inlet.



If voltages are NOT registering, ATTEMPT to activate water volume control valve by turning remote control to highest temperature setting & opening all hot water fixtures.



CAUTION: Hot water temperatures above 120 will scald. Return to original setting once test is complete.

66 – Error Code


Explanation: Water by-pass valve malfunction.

Diagnostic Checks:

- Water bypass valve



IMPORTANT: Prior to measuring voltage, turn remote temperature down to 102 degrees. Water bypass valve will activate at this time.





71 – Error Code

Explanation: Gas control valve malfunction (inlet solenoid).

Diagnostic Checks:

Connector Location
On Page 14

- Gas control valve




72 – Error Code

Explanation: Flame rod(s) malfunction. Flame rod(s) is detecting the presence of flame BEFORE igniter is activated.


Diagnostic Checks:


- Flame rod(s)
- Gas control valve

Connector Location
On Page 14



(See maintenance mode instructions on page 22)





Outdoor: 1 flame rod




Indoor: 2 flame rods



On remote control, go to maintenance mode 0Y table. For maintenance mode instructions go to page 22.

All maintenance mode '0Y' readings should be done immediately after turning the unit ON. IF Flame Rod(s) is detecting flame, maintenance mode will display:

Indoor Units: **05**
Outdoor Units: **01**



On remote control, go to maintenance mode 0Y table. For maintenance mode instructions go to page 22.

All maintenance mode '0Y' readings should be done immediately after turning the unit ON. IF Flame Rod(s) is detecting flame, maintenance mode will display:

Indoor Units: **05**


Outdoor Units: **01**

76 – Error Code


Explanation: Communication fault with remote control.
Remote control is not communicating with control board.

Diagnostic Checks:

- Remote control



Troubleshooting Remote Control Failure



Pressed the "Power ON/OFF" button, but the remote control not is working.

Measure the voltage at the terminal **on the unit.** (※1)

The voltage is **11V to 13V.** (Normal value)

Measure the voltage at the terminal **on the remote control.** (※2)

The voltage is **11V to 13V.** (Normal value)

The remote control failure. **Replace the remote control**

The voltage is less than **10V**

PCB failure **Replace PCB.**

Measure the resistance on the cable connected to remote control (※3)


The resistance is less than **∞Ω** (Normal resistance)

Re-check the cable and the he connection


The resistance is less than **∞Ω** (Cable disconnection)

the cable connected to remote control failure. **Replace the cable**

The location to measure the voltage at the terminal on the unit (※1)




Step.1
Remove the one screw and the remote control connection cover




Step.2
Measure the voltage at the terminal connecting the remote control cable. (Between the terminals(See arrows))



The location to measure the voltage at the terminal on the remote control (※2)




Step.1
Remove the remote control from the base plate




Step.2
Measure the voltage at the terminal connecting the remote control cable. (Between the terminals(See arrows))




The location to measure the resistance at the terminal on the remote control (※3)



Step.1
Remove the cable from the terminal on the unit



Step.2
Remove the cable from the terminal on the remote control



Step.3
Short one side, and measure the resistance at another side of the cable.(See arrows)

79 – Error Code

Explanation: Blower motor current fault.

Diagnostic Checks:

- Blower motor

Turn Power OFF.
Remove control board bracket (How to Remove: Section 1).
Remove blower motor (How to Remove: Section 2).
Clean blower motor and blower motor housing.
Reassemble & operate unit.

Does 79 – Error Code appear?



Locate MIN & MAX buttons on upper right-hand corner of control board.


Continue diagnostics on next page




Unit had a loose connection.

Unit appears to be operating OK.


**MIN & MAX
BUTTONS**




Blower Motor Diagnostics: Indoor Models ONLY




Upper Right-Hand Corner of Control Board



Blower Motor Diagnostics: Outdoor Models ONLY



Upper-Right Hand Corner of Control Board



80 – Error Code

Explanation: Gas control valve malfunction. Unit detected the presence of flame when demand for hot water terminated & the unit turned OFF.

Diagnostic Checks:

- Flame rod(s)
- Gas control valve

Connector Location
On Page 14

Turn Power OFF.
Remove and reinsert connector "M", "T",
and terminal on flame rod(s).
Turn Power ON. Operate unit.
Did 80 – Error Code appear?

Indoor models – 2 flame rods (Connectors "M" & "T").
Outdoor models – 1 flame rod (Connector "M").



Access maintenance mode to check flame rod status. Locate sight glass.
Continue to diagnostic chart on next page





Unit had a loose connection or foreign debris that is no longer present.
Thermistors appear to be OK.

(See maintenance mode instructions on page 22)

FLAME ROD(S)

SIGHT GLASS





Outdoor: 1 flame rod




Indoor: 2 flame rods



On remote control, go to maintenance mode 0Y table. For maintenance mode instructions go to page 22.

All maintenance mode '0Y' readings should be done immediately after turning the unit OFF. IF flame rod(s) is detecting flame, maintenance mode will display:

Indoor Units: **05**
 Outdoor Units: **01**



On remote control, go to maintenance mode 0Y table.
For maintenance mode instructions go to page 21.

All maintenance mode '0Y' readings should be done immediately after turning the unit OFF.

IF Flame Rod(s) is detecting flame, maintenance mode will display:

Indoor Units: **05**
Outdoor Units: **01**

82 – Error Code

Explanation: Control board program chip malfunction.

Connector Location
On Page 14

Diagnostic Checks:

- Program chip

Turn Power OFF.

Verify correct program chip is installed.

YES

Remove and reinsert program chip.

Operate unit.


IF 82 – Error Code appears:

Replace program chip.

NO

Insert correct program chip.

Control Board



90 & 99 – Error Code

Explanation: Unit was operated prior to vent installation
OR unit detected blockage in the venting during pre-purge
OR post-purge cycle.

90 – Error Code will occur BEFORE unit goes to ignition.

99 – Error Code will occur AFTER unit shuts down.

Unit must be reset by performing reset procedure on page 27.

Diagnostic Checks:

- **Perform reset procedure on page 27**
- **VENTING – refer to pages 8-12** or refer to Use & Care manual for installation instructions:
 1. Approved vent materials
 2. Approved terminations
 3. Approved vent lengths
 4. Location and distance between venting (recirculation of exhaust)
 5. Blocked venting
 6. Venting not sealed properly (recirculation of exhaust)
 7. Check Fan Speed:
Check the Y-Checks on starting on Page 22 (Maintenance Mode), specifically for checking fan speed.
 8. Pull, Inspect and Clean Blower

92 & 93 – Error Code

Explanation: **Condensing** Units ONLY:

92 – Error Code: This is a warning code and unit will continue to operate but will eventually shut down.

REPLACE NEUTRALIZER ASAP

Neutralizer rocks made from Calcium Carbonate (CACO3)
Neutralizer kit may be ordered through Rheem/Ruud Supplier.


93 – Error Code: Unit will NOT operate until the Neutralizer is replaced.

REPLACE NEUTRALIZER IMMEDIATELY

Neutralizer rocks made from Calcium Carbonate (CACO3)
Neutralizer kit may be ordered through Rheem/Ruud Supplier.


UNIT MUST BE RESET AFTER NEUTRALIZER IS REPLACED

With remote control ON and no water is running through unit:
Push MIN & MAX buttons at same time – CL is displayed on remote control. Push MIN & MAX buttons again for more than 5 seconds – CL disappears.




HOW TO REMOVE COMPONENTS

OUTDOOR UNIT





INDOOR UNIT




Section 1: Control Board Bracket

ALWAYS TURN OFF Power, Water & Gas



- 1** Remove 'TOP' center screw from control board mounting bracket.



2

Remove connectors: 'M'; 'T'; & 'G'.
Condensing ONLY: ALSO remove connector 'P'.




3

*Remove 2 control board bracket screws located on bottom, outer shell of unit.
*Pull control board bracket out of way to access components.


Section 2: Blower Motor

ALWAYS TURN OFF Power, Water & Gas



Remove control board Bracket to access Blower Motor

Section 1





*Move control board bracket out of way to access blower motor (follow instructions in Section 1).

*Remove 3 OUTER screws from blower motor assembly (circled in red).

*Pull blower motor out of housing.

Section 3: Igniter Rod-Flame Rod-Igniter Coil ALWAYS TURN OFF Power, Water & Gas



Flame Rod(s)

- Flame Rod (FL) #1: Detects presence of flame (Error Code 12)
- Flame Rod (FL) #2: Monitors proper combustion (Error Code 13)

1

- *Disconnect flame rod wire(s).
- *Remove flame rod mounting screws.
- *Pull flame rod(s) out.

IMPORTANT: During reassembly - make sure flame rod gasket is in place. Outdoor (1) Flame Rod, Indoor (2) Flame Rods

Igniter Rod

2




- Disconnect black igniter cable from igniter rod.
- Remove igniter rod mounting screws.
- Pull igniter out.

IMPORTANT:

During reassembly - make sure igniter rod gasket is in place.

Igniter Coil

3





- *Disconnect black igniter cable from igniter rod.
- *Remove igniter coil mounting screw.
- *Disconnect white Molex from igniter coil (circled in blue – has 2 grey wires).



Section 4: Manifold Assembly



ALWAYS TURN OFF Power, Water & Gas



*Move control board bracket out of way (follow instructions in Section 1).


*Remove 12 screws from upper manifold assembly (circled in green).

IMPORTANT: NEVER REMOVE 3 screws directly above manifold assembly (CIRCLED IN RED).



Section 5: Burner Assembly

ALWAYS TURN OFF Power, Water & Gas





- *Move control board bracket out of way (follow instructions in Section 1).
- *Remove manifold assembly (follow instructions in Section 4).
- *Remove 6 screws from burner assembly (circled in green).
- *Pull burner assembly out of heat exchanger housing.

IMPORTANT: NEVER REMOVE 3 bottom screws on burner assembly (CIRCLED IN RED).

IMPORTANT: Orifice assembly and burner assembly screws are different size and type. ALWAYS keep them separate.

Section 6: Gas Control Valve

ALWAYS TURN OFF Power, Water & Gas



*Move control board bracket out of way
(follow instructions in Section 1).

*Remove Manifold Assembly
(follow instructions in Section 4).


*Remove 3 screws for gas inlet connection
located at bottom of unit.

*Remove gas inlet connection.

(Continue to next page)

Section 6: Gas Control Valve

ALWAYS TURN OFF Power, Water & Gas




*Remove 2 Molex connectors and clear tube on left side of gas control valve (circled in green).

*Remove gas control valve and rotate to access Molex connectors on back.

IMPORTANT: During reassembly - make sure ALL 3 gas control valve gaskets are in place.


Back view of gas control valve



*Remove 4 Molex connectors on back of gas control valve (highlighted in corresponding wire color).

*Remove gas control valve.

Front view of gas control valve



IMPORTANT: During reassembly: Make sure ALL 3 gas control valve gaskets are in place.

**Section 7: Water Volume Control &
Water Bypass Valves**
ALWAYS TURN OFF Power, Water & Gas
Use Service Valves to DRAIN UNIT




Remove control board Bracket to access water control valves.

Section 1

(Continue to next page)

Section 7: Water Volume Control & Water Bypass Valves

**ALWAYS TURN OFF Power, Water & Gas
Use Service Valves to DRAIN UNIT**



*Remove 4 screws holding compression fittings in place & remove metal tabs.

*Pull copper pipes out to separate from water valves (1 o-ring on each pipe).

*Remove snap ring (circled in blue).


*Push water volume control towards top of unit to separate from water inlet (1 o-ring).

*Remove water volume control & water bypass valve assembly.

IMPORTANT: During reassembly – make sure ALL O-Rings are on MALE fittings. This will prevent pinching or rolling the O-Rings.

Side View of water control valve

Water bypass valve




Water volume control valve

*Remove snap ring holding water bypass and water volume control valves together (circled in blue).


*Twist water bypass and water volume control valve to separate (1 o-ring).

IMPORTANT: During reassembly – make sure ALL O-Rings are on MALE fittings. This will prevent pinching or rolling the O-Rings.

Section 8: Heat Exchanger thermistors
ALWAYS TURN OFF Power, Water & Gas
Use Service Valves to DRAIN UNIT



1



*Remove 2 screws



OR


Remove snap ring

*Pull Heat Exchanger thermistor out
(O-ring should remain in thermistor well).

NOTE: thermistor has white wire.

To REPLACE thermistor go to diagram 2

2




*Move control board bracket out of way to access Molex for Heat Exchanger thermistor (follow instructions in Section 1).

**NOTE: Non-Condensing – YELLOW Molex
Condensing – GREEN Molex**

*Separate Molex and remove Heat Exchanger thermistor – thermistor is attached to female end of Molex (white wire).


Section 9: Outlet thermistor
ALWAYS TURN OFF Power, Water & Gas
Use Service Valves to DRAIN UNIT



Remove control board Bracket to access
outlet thermistor.

Section 1

1




*Move control board bracket out of way to access outlet thermistor (follow instructions in Section 1).

*Locate Outlet thermistor on lower left side of unit (circled in blue).

*To REPLACE thermistor ONLY: Separate BLACK Molex (circled in green) – thermistor is attached to female end of Molex (black wire).


2



*Remove 2 screws

*Remove Outlet thermistor
(O-ring should remain in thermistor well)


Section 10: Inlet thermistor
ALWAYS TURN OFF Power, Water & Gas
Use Service Valves to DRAIN UNIT



Remove control board Bracket to access inlet thermistor.

Section 1

1




*Move control board bracket out of way to access WHITE Molex for inlet thermistor (follow instructions in Section 1).

* To REPLACE thermistor ONLY: Separate WHITE Molex (circled in green). Thermistor is attached to female end of Molex (white wire).

Water Volume Control Valve

2




*Remove Water Bypass & Water Volume valves (follow instructions in Section 7).

*Remove single screw for the inlet thermistor.


*Remove Inlet thermistor (O-ring should remain in thermistor well).

Section 11: Ambient thermistor
ALWAYS TURN OFF Power, Water & Gas



Remove control board Bracket to diagnose and/or replace ambient thermistor.

Section 1




1

To REPLACE thermistor ONLY:

*Move control board bracket out of way to access BLUE Molex for ambient thermistor (follow instructions in Section 1).

*Separate BLUE Molex (circled in green) – thermistor is attached to female end of Molex (black wire).



2

Non-Condensing Indoor Units

*Remove single screw for the ambient thermistor

(located on back of unit - left of gas control valve– black wire).

*Remove ambient thermistor.

All Outdoor & Condensing Units ONLY:

*Ambient thermistor is located behind the control board near the blower motor (not fastened – black tear drop).

*To locate thermistor: Follow black wire on female end of BLUE Molex.

Section 12: Control Board


ALWAYS TURN OFF Power, Water & Gas

*Remove ALL Molex connections on control board.

*Remove line voltage screws (black & white wires).

*Remove top right mounting screw.

*Remove Fuel Type Chip.



(120 Volt AC ONLY. DO NOT connect any other device)

Section 12: Control Board Replacement Procedure

Recording Manifold Pressure on ORIGINAL Control Board

NOTE: Without this adjustment the water heater may not function properly. (HINT: IF manifold pressure settings are written on the Manifold Assembly, you may skip to next page)

Verify “MINIMUM” Manifold Pressure Setting on Original Control Board

1. The setting value will display on the remote control.
 2. Push and hold down the ADJ button.
 3. While holding the ADJ button, push the MIN button.
 4. Record the number displayed on Remote: _____
 5. Release the ADJ button.
-

Verify “MAXIMUM” Manifold Pressure Setting on Original Control Board

1. The setting value will display on the remote control.
 2. Push and hold down the ADJ button.
 3. While holding the ADJ button, push the MAX button.
 4. Record the number displayed on Remote: _____
 5. Release the ADJ button.
-

Verify “MEDIUM” Manifold Pressure Setting on Original Control Board

1. The setting value will display on the remote control.
2. Locate DIP1 on the control board. Move DIP switch #1 to the ON position (UP).
3. Push MAX button then MIN button within 2 seconds and hold down for more than 5 seconds. Remote will display a “P”. Release both buttons.
4. Push and hold the ADJ button. Setting number will display on the remote (NOTE: you will have 20 seconds to read this value).
5. Record the number displayed on Remote: _____
6. Release the ADJ button.

Section 12: Control Board


Replacement Procedure

Adjusting Manifold Pressure on NEW Control Board

NOTE: This adjustment to be performed on NEW control board.

Adjustment of “MINIMUM” Manifold Pressure Setting on NEW Control Board

1. The setting value will display on the remote control
2. Push and hold down the ADJ button.
3. While holding the ADJ button, push (tap) the MIN button. IF recorded value DOES NOT agree with current value, proceed to next step. IF value DOES agree, release the ADJ button and proceed to **“ADJUSTMENT OF “MAXIMUM” MANIFOLD PRESSURE SETTING ON NEW CONTROL BOARD”** step.
4. IF adjustment is needed, push and hold the ADJ button.
5. While holding the ADJ button, push the MIN button.
6. The current number [01 – 39] will display on Remote.
7. Continue to push the **MIN** button until you get the same value recorded during the **“VERIFY ‘MINIMUM’ MANIFOLD PRESSURE SETTING”** step.
8. **WARNING:** Every time you push the **MIN** button, the display will cycle up to the number 39. Once at 39, it will automatically reverse and cycle back down to 01.
9. Release the **ADJ** button.
10. Continue to **“ADJUSTMENT OF ‘MAXIMUM’ MANIFOLD PRESSURE SETTING”** step.



Section 12: Control Board


Replacement Procedure

Adjusting Manifold Pressure on NEW Control Board

NOTE: This adjustment to be performed on NEW control board.

Adjustment of "MAXIMUM" Manifold Pressure Setting on NEW Control Board

1. The setting value will display on the remote control.
2. Push and hold down **ADJ** button.
3. While holding **ADJ** button, push (tap) the **MAX** button. If recorded value **DOES NOT** agree with current value, proceed to next step. If value **DOES** agree, release the **ADJ** button and proceed to "**ADJUSTMENT OF 'MEDIUM' MANIFOLD PRESSURE SETTING**" step.
4. If adjustment is needed, push and hold down **ADJ** button.
5. While holding the **ADJ** button, push the **MAX** button.
6. The current number [01 – 39] will display on the remote control.
7. Continue to push the **MAX** button until you get the same value recorded during the "**VERIFY 'MAXIMUM' MANIFOLD PRESSURE SETTING**" step.
8. **WARNING:** Every time you press the **MAX** button, the display will cycle up to the number 39. Once at 39, it will automatically reverse and cycle back down to 01.
9. Release the **ADJ** button.
10. Continue to "**ADJUSTMENT OF 'MEDIUM' MANIFOLD PRESSURE SETTING (SLOW IGNITION POINT)**" step.



Section 12: Control Board


Replacement Procedure

Adjusting Manifold Pressure on NEW Control Board

NOTE: This adjustment to be performed on NEW control board.

Adjustment of "MEDIUM" Manifold Pressure Setting on NEW Control Board

1. The setting value will display on the remote control.
2. Locate **DIP1** on control board. Move **DIP switch #1** to **ON** position.
3. Push **MAX** button then **MIN** button within **2 seconds** and hold down for more than **5 seconds**. Remote control will display a "P." Release both buttons.
4. Push and hold **ADJ** button. Setting number will display on remote control (**NOTE:** You have **20 seconds** to read this value).
5. While holding **ADJ** button, push **MIN** button to make the setting go **DOWN** or press the **MAX** button to make the setting to **UP**.
6. Continue until number displayed matches value recorded during the "**VERIFY 'MEDIUM' MANIFOLD PRESSURE SETTING**" step.
7. Follow remaining procedures to return tankless water heater to normal operation.





CONTACT REFERENCE

TANKLESS TECHNICAL SUPPORT

Phone : 1-866-720-2076

Email:

customerservice@rheemtankless.com

GENERAL TECHNICAL SUPPORT

Phone : 1-800-432-8373

Email:

techanalyst@rheem.com

CUSTOMER SERVICE

Parts and Warranty

Phone : 1-800-621-5622

Email:

parts@rheem.com



*In keeping with its policy of continuous progress and improvement,
Rheem reserves the right to make changes without notice.*

Rheem Water Heating ◯ 1115 Northmeadow Pkwy
Roswell, GA 30076 ◯ 1.800.621.5622
www.rheem.com